COMMERCIAL MODELS: 30B THROUGH 180B

CATALOG NO. 9300.9.1 Effective: 02-15-07 Replaces: 07-15-06

RAYPAK ILLUSTRATED PARTS LIST

MODEL SIZES: 30B, 42B, 66B, 90B, 135B & 180B

MODEL TYPE: H3 & H4

DATES OF MANUFACTURE: 10-01-90 THROUGH CURRENT STANDING PILOT


10-01-90 THROUGH 8-11-94 HSI IGNITION 08-12-94 THROUGH CURRENT IID IGNITION MODEL 30B 10-01-90 THROUGH 12-31-00

THE PARTS LISTED ARE FOR STANDARD EQUIPMENT FOR THIS MODEL TYPE. RAYPAK RESERVES THE RIGHT TO SUBSTITUTE, DELETE OR CHANGE ANY PART WITHOUT NOTIFICATION. THE ADDITION OF OPTIONS MAY ALSO CHANGE SOME OF THE PARTS. ORDER REPLACEMENT PARTS FROM ACTUAL HEATER COMPONENTS.



FOR DETAILED INSTRUCTIONS, SEE "HOW TO USE YOUR RAYPAK ILLUSTRATED PARTS LIST", CATALOG NO. 9001.10





| OUT DESCRIPTION 30B 42B 66B 90 B BURNER TRAY 003938F 003938F 004513F 0039 Burner Tray w/ Gas Valve Nat. STG 004753F 004761F 0047 0047 Burner Tray w/ Gas Valve Nat. STG 2 Stage 004802F 004754F 004762F 0047 Burner Tray w/ Gas Valve Pro. STG 004803F 004755F 004763F 0047 Burner Tray w/ Gas Valve Nat. HSI 004803F 004755F 004763F 0047 | 004227F 69F 004805F 61F 70F 004806F 62F 71F 004807F 72F 004808F | 004228F 004793F 004794F |
|---|---|-------------------------------|
| 1-B Burner Tray w/oGas Valve (Sea Level) * Burner Tray w/ Gas Valve Nat. STG Burner Tray w/ Gas Valve Nat. STG 2 Stage Burner Tray w/ Gas Valve Pro. STG Burner Tray w/ Gas Valve Pro. STG 2 Stage Burner Tray w/ Gas Valve Pro. STG 2 Stage Burner Tray w/ Gas Valve Nat. HSI 003938F 004753F 004761F 004761F 0070 004802F 004753F 004762F 004762F 0070 0070 004803F 004755F 004763F 004763F | 99F 004805F 11F 10F 004806F 12F 004807F 12F 004808F | 004793F |
| Burner Tray w/ Gas Valve Nat. STG 004801F 004753F 004761F 0047 0070 | 99F 004805F 11F 10F 004806F 12F 004807F 12F 004808F | 004793F |
| Burner Tray w/ Gas Valve Nat. STG 2 Stage 004754F 004762F 004762F 004762F 004762F 004762F 004762F 004762F 0070 0070 004803F 004755F 004763F 004763 | 004806F 004806F 01F 004807F 004808F | |
| Burner Tray w/ Gas Valve Pro. STG 004802F 004754F 004762F 0047 | 70F 004806F 52F 71F 004807F 72F 004808F | 004794F |
| Burner Tray w/ Gas Valve Pro. STG 2 Stage 004803F 004755F 004763F 0047 | 52F 71F 004807F 72F 004808F | 004794F |
| Burner Tray w/ Gas Valve Nat. HSI 004803F 004755F 004763F 0047 | 71F 004807F 72F 004808F | |
| | '2F 004808F | 004822F |
| Burner Tray w/ Gas Valve Pro. HSI 004804F 004756F 004764F 0047 | | 004823F |
| Burner Tray w/ Gas Valve Pto. HSI 004604F 004756F 004764F 0047 005453F 005455F 00545F 005455F 00545F 005455F 005455F 005455F 005455F 00545F 005455F 00555F 00555F 0055F 0055F 0055F 0055F 0055F 0055F 0055F 0055F 00 | | 004623F 005459F |
| Burner Tray w/Gas Valve Pro. IID 005450F 005451F 005454F 0054 | | 005459F |
| 2-B Burner Spacer/Holddown 0034301 0034321 0034341 0034 | | 0034001 004230F |
| 3-B Burner 301210/3 301210/3 301210/7 3012 | | 301210/15 |
| 4-B Burner Orifice Nat. (Sea Level) * 350347F/3 350079F/3 350347F/7 35008 | | 350080F/15 |
| Burner Orifice Pro. (Sea Level) * 350353F/3 350083F/3 350353F/7 35035 | | 350351F/15 |
| C CONTROLS | | 0000011710 |
| 1-C Adj. Auto High Limit 601003 601003 601003 60100 | 03 601003 | 601003 |
| Staged Controller 6008 | 87 600887 | 600887 |
| 2-C Electronic Fast Response Sensor w/Probe 003943F 003943F 003943F 003943F | 3F 003943F | 003943F |
| 3-C Probe Fast Response 601017 601017 601017 601017 601017 | 17 601017 | 601017 |
| 4-C Roll-Out/Flue Sensor 006021F 006021F 006021F 0060 | 1F 006021F | 006021F |
| G GAS VALVES | | |
| 1-G Combination Valve Nat. Std. Honeywell** 601009 601009 601009 601009 | | |
| Combination Valve Pro. Std. Honeywell 004825F 004825F 004825F 0048 | | |
| Combination Valve Nat. Std. Robertshaw On/Off 601009 601009 601009 60100 | | |
| Combination Valve Pro. Std. Robertshaw On/Off 004825F 004825 | | 00.400.45 |
| Combination Valve Nat. Std. Robertshaw 2 Stage 0048 | | 004824F |
| Combination Valve Pro. Std. Robertshaw 2 Stage 00485 | | 004825F |
| Combination Valve Nat. HSI Honeywell 601015F 601015F 601015F 601016F 60101 | | |
| Combination Valve Pro. HSI Honeywell 601016F 601016F 601016F 6010 601016F | | 004826F |
| Combination Valve Nat. HSI Robertshaw 005095F 0050 | | 004827F |
| Combination Valve P10. FISH Robertshaw 0030901 003 | | 0040271 |
| Combination Valve Nat. IID Honeywell On/Off 006958F | | |
| Combination Valve Nat. IID Robertshaw On/Off 005461F 005461F 005461F 005461F 005461F | | |
| Combination Valve Pro. IID Robertshaw On/Off 005462F 005462F 005462F 005462F 005462F | | |
| Combination Valve Nat. IID Robertshaw 2 Stage 0054 | | 005463F |
| Combination Valve Pro. IID Robertshaw 2 Stage 0054 | | 005464F |
| H HEAT EXCHANGER | | |
| 1-H Heat Exchanger Cast Iron 003945F 003945F 003946F 0039 | | 004232F |
| Heat Exchanger Brass N/A N/A N/A N/A | | N/A |
| 2-H Inlet/Outlet Header Cast Iron 003950F 003950F 003952F 0039 | | 004236F |
| Inlet/Outlet Header Brass N/A N/A N/A N/A | | N/A |
| 3-H Return Header Cast Iron 003954F 003956F 0039 | | 004240F |
| Return Header Brass N/A | | N/A |
| 4-H Tube Bundle ¹ 003959F 003959F 003960F 0039 | | 004244F |
| 5-H Heat Exchanger Tube 003961F 003961F 003961F 003964F 003964F | | 003961F |
| 6-H Baffle Kit 003963F 003963F 003964F 0039 7-H Carriage Bolt Kit 003965F 003965F 003965F 0039 | | 004246F |
| 7-H Carriage Bolt Kit 003965F 003965F 003965F 003965F 003965F 007912F | | 004248F 007911F |
| 8-H Header Gasket 800203B 800203B 800203B 8002 | | 800203B |
| 9-H Sensor Well 007211F 007211F 007211F 0072 | | 000203B 007211F |
| 10-H Well Retaining Clip 300203 300203 300203 300203 | | 300203 |
| J CONTROL BOX | 300200 | 000200 |
| 1-J Control Box Std. (Complete) 003966F 003966F 003966F 0039 | 6F 004249F | 004249F |
| Control Box Std. 2- Stage (Complete) 0070 | | 007023F |
| Control Box HSI (Complete) | 7F 004250F | 004250F |
| Control Box IID Nat/Lock (Complete) 005465F 005465F 005465F 0054 | | 005466F |
| Control Box IID Nat/Lock 2 Stage (Complete) 0070 | 2F 007024F | 007024F |
| 2-J Transformer 650691 650691 650691 650691 | 91 650691 | 650691 |
| 3-J Relay DPST 650518 650518 650518 650518 650518 650518 6505 | 18 650518 | 650518 |

^{**}HONEYWELL GAS VALVE NO LONGER AVAILABLE. REPLACEMENT IS ROBERTSHAW.

^{*}FOR ALTITUDES ABOVE 2,000 FEET ABOVE SEA LEVEL, CONSULT FACTORY.

¹NUMBER OF TUBES VARIES FOR EACH MODEL SIZE.

| DESCRIPTION | 30B | 42B | 66B | 90B | 135B | 180B | | | |
|---------------------|--|------------|------------|-------------------------|------------|--------------------|--|--|--|
| MISCELLANEOUS | | | | | | | | | |
| | 501410 | | | 501410 | 501410 | 501410 | | | |
| | | | | | | 052871F | | | |
| | | | | | | 007205F | | | |
| | | | | | | 006536F | | | |
| | | | | | | 005097F | | | |
| | 007340F | 007340F | 007340F | 007340F | | 007333F | | | |
| | | | | | | 004714F | | | |
| | | | | | | 951166F | | | |
| | 003969F | 003969F | 003969F | | | 004256F | | | |
| 9 | | | | | | 007044F | | | |
| | | | | | | 004257F | | | |
| | | | | | | 004258F | | | |
| | 005602F | 005602F | 005602F | | | 005603F | | | |
| | | | | | | 007045F | | | |
| , | | | | | | 009064F | | | |
| | 009065F | 009065F | 009065F | 009065F | 009066F | 009066F | | | |
| | 0000705 | 0000705 | 0000705 | 0000705 | 0000705 | 2222725 | | | |
| | | | | | | 003972F | | | |
| | | | | | | 003973F | | | |
| | | | | | | 005467F | | | |
| | | | | | | 005468F | | | |
| | | | | | | 003974F | | | |
| | | | | | | 003975F | | | |
| | | | | | | 003903F 004308F | | | |
| | | | | | | | | | |
| | | | | | | 600003 003976F | | | |
| | | | | | | 601005F | | | |
| | | | | | | 601129F | | | |
| | | | | | | 0011231 004935F | | | |
| , | | | | | | 306239 | | | |
| | | | | | | 400275 | | | |
| | | | | | | 002654B | | | |
| | | | | | | 007864F | | | |
| | 0070041 | 0070041 | 0070041 | 0070041 | 0070041 | 0070041 | | | |
| | 003977F | 003977F | 003978F | 003978E | 004259F | 004260F | | | |
| | 5505771 | 5000771 | 5505751 | 5505751 | 307Z001 | 5072001 | | | |
| | 003979F | 003979F | 003980F | 003980F | 004261F | 004268F | | | |
| Flue Collector | | | | | | 004263F | | | |
| Access Panel | 003983F | 003983F | 003983F | 003983F | | 004264F | | | |
| Control Panel Cover | 003984F | 003984F | 003984F | 003984F | 004265F | 004265F | | | |
| Jacket-LT | 009170F | 009170F | 009170F | 009170F | 009170F | 009170F | | | |
| Jacket-RT | 009171F | 009171F | 009171F | 009171F | 009171F | 009171F | | | |
| Jacket-RR | | | | | | 009173F | | | |
| VENTING | | | | | | | | | |
| Drafthood | 003985F | 003985F | 003986F | 003986F | 004266F | 004267F | | | |
| | 4709 | | | | | 004712 | | | |
| | PRV 30 PSI Deliming Kit T & P Gauge Drain Valve Pump Inline Taco Pump Inline Taco Brass Pump Inline Grundfos Pump Cartridge (Taco) Wire/Harness Std. Wire/Harness Std. 2 Stage Wire/Harness HSI Honeywell Wire/Harness HSI Fenwal Wire/Harness IID Wire/Harness IID 2 Stage Flange Gasket (Not Shown) Bypass Group PILOT Pilot Nat. Std. Pilot Pro. IID Pilot Orifice Nat. Std. Pilot Orifice Pro Std. Pilot Orifice Nat. IID Pilot Thermocouple Hot Surface Ignitor HSI Ignition Control HSI Honeywell Ignition Control HSI Honeywell Pilot Mtg. Bracket Pilot Tube High Tension Wire IID High Tension Wire w/Pilot Electrode REFRACTORY Refractory Kit SHEETMETAL Jacket-Top Flue Collector Access Panel Control Panel Cover Jacket-RT Jacket-RR VENTING | PRV 30 PSI | PRV 30 PSI | PRV 30 PSI Deliming Kit | PRV 30 PSI | Deliming Kit | | | |

| GAS CONVERSION KITS ** *** | 30B | 42B | 66B | 90B | 135B | 180B |
|-------------------------------------|---------|---------|---------|---------|---------|---------|
| HONEYWELL GAS VALVE | | | | | | |
| Standing Pilot Nat. to Pro. On/Off | *** | *** | *** | *** | | |
| Standing Pilot Pro. to Nat. On/Off | *** | *** | *** | *** | | |
| Hot Surface Ignition Nat. to Pro. | 004271F | 004275F | 004700F | 004279F | | |
| Hot Surface Ignition Pro. to Nat. | 004272F | 004276F | 004701F | 004280F | | |
| IID Nat. to Pro. Honeywell On/Off | 005471F | 005473F | 005475F | 005477F | | |
| IID Pro. to Nat. Honeywell On/Off | 005472F | 005474F | 005476F | 005478F | | |
| ROBERTSHAW GAS VALVE | | | | | | |
| Standing Pilot Nat. to Pro. On/Off | 004289F | 004293F | 004702F | 004297F | 004281F | 004285F |
| Standing Pilot Pro. to Nat. On/Off | 004290F | 004294F | 004703F | 004298F | 004282F | 004286F |
| Standing Pilot Nat. to Pro. 2 Stage | | | | 010808F | | |
| Standing Pilot Pro. to Nat. 2 Stage | | | | 010809F | | |
| Hot Surface Ignition Nat. to Pro. | 004291F | 004295F | 004704F | 004299F | 004283F | 004287F |
| Hot Surface Ignition Pro. to Nat. | 004292F | 004296F | 004705F | 004300F | 004284F | 004288F |
| IID Nat. to Pro. Robertshaw On/Off | 005479F | 005481F | 005483F | 005485F | 005487F | 005489F |
| IID Pro. to Nat. Robertshaw On/Off | 005480F | 005482F | 005484F | 005486F | 005488F | 005490F |
| IID Nat. to Pro. Robertshaw 2 Stage | | | | 010810F | | |
| IID Pro. to Nat. Robertshaw 2 Stage | | | | 010811F | | |

** Gas Conversions are to be done only by a Qualified Agency.

*** Gas conversion only available in Robertshaw valve.

IGNITION CONTROL CONVERSION KIT Robertshaw HSI Control to Fenwal HSI Control 004678F

NOTE: BOILERS MANUFACTURED AFTER AUGUST 11, 1994, SERIAL #9408116901 OR LATER, HAVE IID IGNITION IN LIEU OF HSI IGNITION.

